

Extendable Coffin Trolley SW-1250



The extendable coffin trolley SW-1250 has an extremely rugged, torsion-resistant x-frame structure completely made of stainless steel. This material makes a great visual impact and is very easy to clean. The extendable trolley is designed for everyday use in the funeral and cemetery sector. Due to the very light weight the extendable trolley can easily be transported in funeral cars. When folded it can be secured via a locking mechanism. Equipped with 4 steerable rollers - 2 rollers with locking device $d=200\text{mm}$ the trolley is very mobile and can be moved trouble-free over uneven ground. 6 little stainless steel bolts on the upper frame serve as support for the coffin.

Technical Data:

Dimensions folded W/D/H:	540 x 215 x 755 mm
Dimensions unfolded W/D/H:	540 x 1265 x 565 mm
Carrying capacity:	max. 300 kg
Dead weight:	approx. 25 kg
Material:	Stainless steel (Material No. 1.4301 – ANSI 304)
Type:	SW-1250
Article No.:	050.166.100

Accessories see back page

KUGEL medical GmbH & Co. KG
Hermann-Köhl-Str. 2A
DE - 93049 Regensburg/Germany

Phone +49/941/20 86 48-0
Fax +49/941/20 86 48-29
www.KUGEL-medical.de



Extendable Coffin Trolley SW-1250

Accessories



Extendable Coffin Trolley SW-1250-VE with Elastic Wheels

As described above, but with 4 elastic wheels, 2 of them lockable

Type: SW-1250-VE
Article No.: 050.166.170



Extendable Handles Made of Stainless Steel for ST-1250

Handles are extendable on the side approx. 150 mm,
1 Set = 4 handles

Type: GR-SW-1250
Article No.: 050.166.107

KUGEL medical GmbH & Co. KG
Hermann-Köhl-Str. 2A
DE - 93049 Regensburg/Germany

Phone +49/941/20 86 48-0
Fax +49/941/20 86 48-29
www.KUGEL-medical.de

