

Lift and Transport Truck HTW 50/150

Special Height – 2100 mm



The lift- and transport truck has a rugged, torsion-resistant frame structure, grey powder-coated with smoothly running, integrated hydraulic unit for foot-actuated vertical adjustment enables easy handling. 4 steerable solid rubber wheels, 2 of them lockable, 1 enabling locking as regards to the direction, d = 125 mm with special roller bearings, permanently lubricated and maintenance-free, which ensure an absolutely noiseless movement. A stainless steel roller track comprising 5 carrying rollers of corrosion-resistant material and plastic coating has been arranged on top of the truck. A holding device secures the body tray or coffin plate lying on it. The slide handle of the lift and transport truck can be removed. An anti-collision buffer is mounted to the front end.

Technical Data:

Dimensions lowest Position W/D/H:	2500 x 750 x 300 mm
Dimensions highest Position W/D/H:	2500 x 750 x 2100 mm
Carrying capacity:	max. 250 kg
Dead weight:	approx . 130 kg
Material:	Steel
Colour:	Lightgrey RAL 7035 (powder coated)
Type:	HTW 50/150
Article No.:	050.070.010

Lift and Transport Truck HTW 50/150 – 350 kg

Material: Steel Article No.: 050.070.021

Additional models see back page

KUGEL medical GmbH & Co. KG
Hermann-Köhl-Str. 2A
DE - 93049 Regensburg/Germany

Phone +49/941/20 86 48-0
Fax +49/941/20 86 48-29
www.KUGEL-medical.de



Lift and Transport Truck HTW 51/150

Special Height – 2100 mm – Made of Stainless Steel

The lift and transport truck has a rugged, torsion-resistant frame structure, completely made of stainless steel (Material no. 1.4301 – ANSI 304) with smoothly running, integrated hydraulic unit for foot-actuated vertical adjustment for easy handling. 4 steerable solid rubber wheels, 2 of them lockable, 1 enabling locking as regards to the direction, d = 125 mm with special roller bearings, permanently lubricated and maintenance-free, which ensure an absolutely noiseless movement. A stainless steel roller track comprising 5 carrying rollers of corrosion-resistant material and plastic coating has been arranged on top of the truck. A holding device secures the body tray or coffin plate lying on it. The slide handle of the lift and transport truck can be removed. An anti-collision buffer is mounted to the front end.

Technical Data:

Dimensions lowest Position W/D/H:	2500 x 750 x 320 mm
Dimensions highest Position W/D/H:	2500 x 750 x 2100 mm
Carrying capacity:	max. 250 kg
Dead weight:	approx. 130 kg
Material:	Stainless steel (Material No. 1.4301 – ANSI 304)
Type:	HTW 51/150
Article No:	050.140.010

Lift and Transport Truck 51/150 – 350 kg

Material: Stainless Steel Article No.: 050.140.021

KUGEL medical GmbH & Co. KG
Hermann-Köhl-Str. 2A
DE - 93049 Regensburg/Germany

Phone +49/941/20 86 48-0
Fax +49/941/20 86 48-29
www.KUGEL-medical.de

