

Lift and Transport Truck HTW 50/010

Basic Model



The model above shows the Lift and Transport Truck HTW 51/010 made of stainless steel

The lift and transport truck has a rugged, torsion-resistant frame structure and is made of powder coated steel (grey – RAL 9007). Additionally, it has a smoothly running, integrated hydraulic unit for foot-actuated vertical adjustment for easy handling, 4 steerable solid rubber wheels, 2 of them lockable, 1 enabling locking as regards to the direction, d = 125 mm with special roller bearings, permanently lubricated and maintenance-free, which ensure an absolutely noiseless movement. A roller track comprising 4 carrying rollers, as well as a holding device for a body tray have been arranged on top of the truck. The slide handles of the lift and transport truck can be removed. The low deadweight permits straightforward shunting and operation of the lift and transport truck. A special valve ensures even lowering at various loads.

Technical Data:

Dimensions lowest Position W/D/H:	2150 x 750 x 320 mm
Dimensions highest Position W/D/H:	2150 x 750 x 1650 mm
Carrying capacity:	max. 250 kg
Dead weight:	approx. 100 kg
Material:	Steel
Colour:	Light grey RAL 9007 (powder coated)
Type:	HTW 50/010
Article No.:	050.010.650

KUGEL medical GmbH & Co. KG
Hermann-Köhl-Str. 2A
DE - 93049 Regensburg/Germany

Phone +49/941/20 86 48-0
Fax +49/941/20 86 48-29
www.KUGEL-medical.de

