

Lift and Transport Truck HTW 50/050-SRS

Light-Weight Construction



Especially light-weight and yet rugged, torsion-resistant steel frame structure, grey-painted with smoothly running, integrated hydraulic unit for foot-actuated vertical adjustment. The lift- and transport truck is equipped with 4 steerable wheels, 2 of them lockable, 1 enabling locking as regards to the direction, diameter 200 mm with special ball bearings, permanently lubricated and maintenance-free, which ensure an absolutely noiseless movement.. The HTW 50/050 has been particularly designed for the transportation inside hospitals and/or for transferring coffins out of the funeral car. The extremely low dead weight allows easy shunting and operation. A special valve ensures even lowering at various loads. The upper construction is equipped with stainless steel profile tracks and a moveable / fixable sliding carriage. On the front side is a carrying roller for easy transferring of coffins in or out of funeral cars. The slight handle can be removed.

Technical Data:

Dimensions lowest Position W/D/H:	1700 x 710 x 465 mm
Dimensions highest Position W/D/H:	1700 x 710 x 1265 mm
Carrying capacity:	max. 250 kg
Dead weight:	approx. 85 kg
Material:	Steel
Colour:	grey painted
Type:	HTW 50/050-SRS
Article No:	050.010.005

KUGEL medical GmbH & Co. KG
Hermann-Köhl-Str. 2A
DE - 93049 Regensburg/Germany

Phone +49/941/20 86 48-0
Fax +49/941/20 86 48-29
www.KUGEL-medical.de

