

# Lift and Transport Truck HTW 50/101 for Sideway Loading



The lift and transport truck has a rugged, torsion-resistant frame structure and is made of powder coated steel (grey – RAL 7035). Additionally, it has a smoothly running, integrated hydraulic unit for foot-actuated vertical adjustment for easy handling. 4 steerable solid rubber wheels, 2 of them lockable, 1 enabling locking as regards to the direction,  $d = 125$  mm with special roller bearings, permanently lubricated and maintenance-free, which ensure an absolutely noiseless movement. The extremely low deadweight permits straightforward shunting and operation of the lift and transport truck. A special valve ensures even lowering at various loads. On the top the lift and transport truck is equipped with two U-profiles to accommodate the body tray (Type LM 80/101) with 4 wheels. The slide handle of the lift and transport truck can be removed. An anti-collision buffer is mounted to the front end.

## **Technical Data:**

Dimensions lowest Position W/D/H:	2150 x 750 x 260 mm
Dimensions highest Position W/D/H:	2150 x 750 x 1610 mm
Carrying capacity:	max. 250 kg
Dead weight:	approx. 100 kg
Material:	Steel
Colour:	Lightgrey RAL 7035 (powder coated)
Type:	HTW 50/101
Article No.:	050.020.010

*Additional models see back page*

**KUGEL medical GmbH & Co. KG**  
Hermann-Köhl-Str. 2A  
DE - 93049 Regensburg/Germany

Phone +49/941/20 86 48-0  
Fax +49/941/20 86 48-29  
[www.KUGEL-medical.de](http://www.KUGEL-medical.de)



**KUGEL**  
*medical*  
■ ■ ■ ■

# Lift and Transport Truck HTW 50/101 for Sideway Loading – Made of Stainless Steel

The lift- and transport truck has a rugged, torsion-resistant frame structure and is completely made of stainless steel (Material no. 1.4301 – ANSI 304). Additionally it has a smoothly running, integrated hydraulic unit for foot-actuated vertical adjustment for easy handling. 4 steerable solid rubber wheels, 2 of them lockable, 1 enabling locking as regards the direction,  $d = 125$  mm with special roller bearings, permanently lubricated and maintenance-free, which ensure an absolutely noiseless movement. The extremely low deadweight permits straightforward shunting and operation of the lift and transport truck. A special valve ensures even lowering at various loads. On the top the lift and transport truck is equipped with two U-profiles to accommodate the body tray (Type LM 80/101) with 4 wheels. The slide handle of the lift and transport truck can be removed. An anti-collision buffer is mounted to the front end.

## Technical Data:

Dimensions lowest Position W/D/H:	2150 x 750 x 260 mm
Dimensions highest Position W/D/H:	2150 x 750 x 1610 mm
Carrying capacity:	max. 250 kg
Dead weight:	Stainless steel (Material No. 1.4301 – ANSI 304)
Type:	HTW 51/101
Article No.:	050.090.020

**KUGEL medical GmbH & Co. KG**  
Hermann-Köhl-Str. 2A  
DE - 93049 Regensburg/Germany

Phone +49/941/20 86 48-0  
Fax +49/941/20 86 48-29  
[www.KUGEL-medical.de](http://www.KUGEL-medical.de)



**KUGEL**  
*medical*  
■ ■ ■ ■