

Roller Track with Digital Weighing Device RBW-WA-200



Completely electronic weighing unit for fast and reliable weighing. You can tare and weight at the same time with only one button. Rugged stainless steel frame structure with roller track installed on the top comprising 5 carrying rollers and central locking for safe fixing of the overlying body trays during the weighing process. The roller track is compatible with the roller system of both, morgue coolers and lift and transport trucks. Frame with integrated weighing device, digital display with installed battery (approx. 8 hours battery-supplied handling). Indicator with coiled cord for wall fastening. The weighing device is fastened directly to a wall provided by the customer. Delivery includes a 230 Volt recharger.

Technical Data:

Dimensions W/D/H:	2000 x 680 x 600 mm
Dimension Display W/D/H:	250 x 100 x 50 mm
Weight	60 kg
Material:	Brushed stainless steel (Material No. 1.4301 – ANSI 304)
Carrying capacity:	max. 200 kg
Weighting range:	0 – 200 Kg
Precision:	+ / - 500 g
Type:	RBW-WA-200
Article No.:	090.010.110

KUGEL medical GmbH & Co. KG
Hermann-Köhl-Str. 2A
DE - 93049 Regensburg/Germany

Phone +49/941/20 86 48-0
Fax +49/941/20 86 48-29
www.KUGEL-medical.de

